
LIMB EATING ZOMBIE BOY

INSTALLATION AND OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN





PARTS

- 1. HEAD, BODY, SHOES AND MODULE
- 2. METAL BASE
- 3. 6V 2A ADAPTER
- 1. Line up metal leg posts on **HEAD,BODY,SHOES AND MODULE** with posts on **METAL BASE**. Place **HEAD,BODY,SHOES AND MODULE** on the **METAL BASE**.
- 2. Open hook and loop opening in back of **HEAD,BODY,SHOES AND MODULE** and Insert 4 AA batteries (not included) into **MODULE**or connect **6V 2A ADAPTER**.

Note: Turn switch on MODULE to ON to operate in Timer/Sound & Motion activation mode. (Limb Eating Zombie Boy will function with 3 minute breaks between cycles - or, clap during 3 minute break to instantly start playing again). Leave switch in OFF position when not in use.







LIMB EATING ZOMBIE BOY

INSTALLATION AND OPERATING INSTRUCTIONS


KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

Optional Footpad Setup

Follow steps #1 through 3 on initial installation first.

- 1. Connect the cable from the optional footpad to the jack labeled FOOTPAD located on the base.
- 2. Place the switch on the module into the 'FOOTPAD' position to enable FOOTPAD activation.
- 3. Step on FOOTPAD to activate the scary sequence. (go to instruction #4 to continue setup)

*Footpads are sold separately and can be purchased at www.spirithalloween.com



OUTDOOR WARNING: For best overall performance, we recommend you to operate your item in a sheltered outdoor area. We also recommend you bring your item indoors during adverse weather (extreme cold, strong winds and/or rain). This item operates best outdoors in temperatures above freezing (32°F). Tekky Toys recommends using fresh alkaline batteries for best operating performance.



Surface washable only.
ALL NEW MATERIALS:
PLASTIC, POLYESTER,
POLYESTER FIBER
LIMB EATING ZOMBIE BOY is
a trademark of TEKKYTOYS
Copyright © 2013 TEKKYTOYS
All Rights Reserved.
MADE IN CHINA



SMART PHONE SCAN
SETUP VIDEO

Warning! This item is not a toy. For decoration only. Small parts, choking hazard.
This product is intended for use by persons 15 years of age and older.
Not intended for use by children ages 14 years and younger.

