

Evil glowing eyes & zombie cries!

# ZOMBIE DOLLS" BRIDE



3 LR44 button cell batteries required (included for demo purposes only)

Se necesitan 3 pilas de botón LR44 (Incluidas solo para fines de demostración) TRY MEI PRESS BUTTON ON CHEST

IPRUÉBAME! PRESIONA EL BOTÓN EN EL PECH

### She's the GHOUL of your dreams! Evil glowing eyes and zombie cries!

# **OPERATING INSTRUCTIONS**

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

- Insert 3 brand new button cell LR44 batteries into the battery compartment located on back of your Zombie Doll™.
- 2. Press the button on Doll's chest to activate scary sequence!

SURFACE WASHABLE ONLY. All new materials: polyester fibres, plastic, wire

Item #58637 ZOMBIE DOLL<sup>TM</sup> BRIDE<sup>TM</sup> is a trademark of Tekky. Copyright © 2018 Tekky. All Rights Reserved. MADE IN CHINA

> Manufactured for and distributed by: Tekky, Orland Park, IL 60467 USA

## TekkyDesign.com

Also available! TAMMY TERROR™ (57501) BLOODY MARY™ (57502)

WARNING! CHOKING HAZARD—Small Parts. This item is not a toy. For decoration only. This product is intended for use by persons 15 years of age and older. Not intended for use by children 14 years of age and younger.

# BATTERY INSTRUCTIONS & CAUTIONS

- Battery installation and removal should be performed by an adult.
- · Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- · Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickelcadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- · Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- · Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.

