


COAT RACK MONSTER

INSTALLATION AND OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN


PARTS

1. HEAD WITH MODULE AND CLOTHING
2. WOODEN BASE
3. METAL POLE
4. COAT RACK BASE
5. HATS
6. ADAPTER



1. Remove wire twist ties and cardboard from underneath the **WOODEN BASE**.
2. Snap lock **METAL POLE** into **WOODEN BASE**. (Match A to A)
3. Slide the **COAT RACK BASE** over the **METAL POLE** so it is covering the **WOODEN BASE**.
4. Hold the **METAL POLE** near the base and extend the pole upwards with your other hand until the **METAL POLE** has locked into place. The pole is fully extended when you hear two audible clicks.
5. Snap lock **METAL POLE** to underside of **HEAD WITH MODULE AND CLOTHING**. (Match B to B)
6. Connect the **ADAPTER** or insert 4 AA batteries (not included) into the battery compartment located on **MODULE**. *Battery compartment and **MODULE** are located underneath the clothing.


Note: Turn the switch to the **ON** position to operate in Sound or Motion activation mode. Make a loud sound (clap), or move in front of the item to activate. Turn the switch to **MOTION** to operate in Motion activation only. Turn item **OFF** when not in use.



Optional Footpad Setup


Follow steps #1 through 6 on initial installation first.

1. Connect the cable from the optional footpad to the jack labeled FOOTPAD located on the module.
2. Flip the switch on the base to the 'FOOTPAD' position to enable FOOTPAD activation.
3. Step on FOOTPAD to activate the scary sequence. (go to instruction # 7 to continue setup)



*Footpads are sold separately and can be purchased at www.tekkytoys.com

7. Pulling the clothing down, adjust the coats, scarf and pose arms facing outwards. **IMPORTANT: STRAIGHTEN METAL WIRE ARMS SO THAT THEY ARE POSITIONED STRAIGHT OUT WHEN HEAD IS IN UPWARD POSITION FOR ITEM TO FUNCTION PROPERLY. See illustration 7**
8. Place **HATS** on wire posts extending from shoulders.
9. Adjust sound with **VOLUME CONTROL KNOB** located on the **MODULE** as needed.



visit us at tekkytoys.com

Surface Washable Only.
 ALL NEW MATERIALS : WOOD, METAL,
 PLASTIC, FOAM, POLYESTER,
 POLYESTER FIBER
 Requires 4 'AA' Batteries (Not included)
 or 6V 2A DC adapter (included)
 COAT RACK MONSTER is a
 trademark of Tekky Toys.
 Copyright © 2014 Tekky Toys.
 All Rights Reserved.
 MADE IN CHINA



DO NOT RETURN THIS ITEM TO THE STORE!
 If experiencing technical difficulties, please go to
www.tekkytoys.com for assistance.

Tekky Toys Hours of Operation: Monday - Friday 9am to 5pm CST
T: 708-478-8424 E: support@tekkytoys.com
 visit us: tekkytoys.com