# **EASY ASSEMBLY AND OPERATION INSTRUCTIONS**

5124293 Clawing Cathy



This item, when assembled by the following instructions, should take 15 minutes to assemble. Please follow the step by step guide and enjoy your Clawing Cathy!


## CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors or in a sheltered outdoor area. We also recommend that you bring your item indoors during adverse weather (extreme cold, strong winds and/or rain). When not in use, store this product in it's original packaging. Keep away from heat and moisture.


#### WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children. This product is intended for people ages 14 and up.

Please read all instructions carefully before assembling. Save this instruction sheet for future reference.



BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX. IF ANY PART IS MISSING, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT CUSTOMER SERVICE FROM 8:30AM TO 5:30PM PST AT 1-855-428-3921. EXT. 207.




Place Torso Frame (A) on the floor with the flat side down.

Plug in the UL Power Adapter into the input jack marked "DC 6V" on the Function Control Box and route the power cord towards the back of the Torso Frame (A).

Note: Do not plug UL Power Adapter into a power outlet until item assembly is complete.


Optional: If you choose to use the Step Here Try-Me Activation Pad (F), plug the connector into the input jack marked "TRY ME" on the Function Control Box and route the Step Here Pad (F) towards the back of the Torso Frame (A). Once the item is fully assembled set the Step Here Pad (F) in front of the character.




#### STEP 2

Slide Costume (B) over the Torso Frame (A) as shown. Note the hook and loop closer on the neck opening should be closest to the floor.

2014 0501



Now secure the Head (C) by sliding the head post on top of the Torso Frame (A) and aligning the quick-connect push buttons into the pre drilled holes. Attach the head hook to the Torso Frame (A) by removing the provided cotter pin from the head hook and sliding it through the Control Bar ring. Secure by replacing the cotter pin. Connect the color coded male/female cable from the Head (C) to the Function Control Box as shown




#### STEP 4

Now run the Left Hand (D) up through the left sleeve and secure the forked-hook into the slot housing at the "elbow" of the Torso Frame (A). Repeat this step for the Right Hand (E). Now locate the pre-cut hole in the front of the costume (B) and place it around the IR sensor located at the front of the Torso Frame (A) and secure with the hook and loop closure. Make sure the IR sensor is not obstructed.



### STEP 5

Close the sides and the front of the Costume (B) with the hook and loop closures provided. Your Clawing Cathy is now fully assembled and ready to be plugged in and enjoyed!



#### **OPERATION INSTRUCTIONS**

- 1. Plug the UL Power Adapter into a standard power outlet and adjust the settings on the Function Control Box to your liking.
- 2. The Clawing Cathy has 3 operation settings which can be found on the main Function Control Box on the (D) Torso Frame:
- · On: This setting allows the item to run continuously.
- On: This setting allows the item to only be activated when the infra-red sensor is activated. The item will operate for one audio-cycle with each sensor activation.
  The Infra-red (IR) sensor will activate when someone comes within an 80-degree

  - The Infra-red (IR) sensor will activate when someone comes within an au-degree angle from left-to-right, as well as from above and below.
    The Infra-red (IR) sensor has a range of up to 2 meters/6.56 feet, and can work in all lighting conditions bright light to no-light!
    NOTE: Upon first operation, the infra-red (IR) sensor will take approximately 30 seconds to calibrate to its surroundings; once calibrated, the IR sensor will allow the item to operate quickly once activated operate quickly once activated.
- Try-Me: This setting allows the item to be activated only when the TRY Me Step Here Pad is activated. The item will operate for one audio-cycle with each Try-Me activation.

The Function Control box also includes a Volume Control knob, which allows you to adjust the volume to be as loud or as quiet as needed. Be sure to test the item before finalizing your display so you can set the volume to your liking.

ENJOY YOUR CLAWING CATHY!