


HAUNTED LAMP™

INSTALLATION AND OPERATING INSTRUCTIONS






KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

PARTS

1. LAMP BASE
2. LAMP SHADE
3. LIGHTING MODULE



1. Insert **LIGHTING MODULE** into **LAMP BASE**. Line up groove on **LAMP BASE** and firmly insert to secure.
* The **LIGHTING MODULE** is fully inserted when the lip on the **MODULE** touches the **LAMP BASE**.
2. Insert **LAMP SHADE** into **LIGHTING MODULE**. Gently twist to lock.
3. Insert brand new "AA" Alkaline batteries into the battery compartment located on the bottom of the **LAMP BASE**.
4. Gently pull string on **LIGHTING MODULE** to turn on light.
5. To operate in Sound/Motion activation mode, make a loud sound (clap) or move in front of item to activate the scary sequence.



Battery Instructions and Cautions:

- Use only the batteries recommended by the manufacturer.
- Remove batteries when not in use.
- Do NOT use rechargeable batteries.
- Be sure to insert the batteries with the correct polarity +/-.
- Never mix different types of batteries: old and new, carbon-zinc, alkaline, nickel-cadmium or rechargeable.
- Always dispose of exhausted batteries properly. Do NOT dispose of batteries in fire, they may leak or explode.

ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.

WARNING
DO NOT TURN ITEM ON UNTIL YOU HAVE COMPLETELY FINISHED ASSEMBLY.
DO NOT PLACE ITEM ON UNEVEN SURFACE.
DO NOT PLACE WEIGHT ON ITEM WHILE IN OPERATION.



DO NOT RETURN THIS ITEM TO THE STORE!
If experiencing technical difficulties, please go to www.tekkytoys.com for assistance.



visit us at tekkytoys.com

Requires 3 'AA' Batteries sold separately.

Surface washable only.

ALL NEW MATERIALS:
PLASTIC, POLYESTER,
POLYESTER FIBER