



# ASSEMBLY AND OPERATING INSTRUCTIONS FOR M37763

**MORBID**  
ENTERPRISES  
www.morbidenterprises.com


## ARTS




**ASSEMBLE BASE, SHOES AND LEG POLES AS SHOWN BELOW:**




**SLIDE THE PANTS LEGS OVER AND DOWN. EACH POLE AND ATTACH THIGH POLES AS SHOWN BELOW:**



**NEXT ATTACH THE TORSO FRAME AND WAIST RING TO THE THIGH POLES.**




**4 GENTLY PULL THE OUTFIT UPWARDS UNTIL IT REACHES THE MIDDLE OF THE TORSO FRAME, THEN INSERT THE LEFT ARM THROUGH THE LEFT SLEEVE AND ATTACH IT THROUGH THE LEFT SHOULDER.**




**DO THE SAME FOR THE RIGHT ARM.**


**5 ATTACH THE SHOULDER COVER TO THE TORSO FRAME AND PULL THE OUTFIT OVER IT.**




**6 NEXT ATTACH THE HEAD TO THE NECK FRAME, THEN CONNECT THE MALE JACKS FROM THE HEAD TO THE FEMALE JACKS FROM THE TORSO FRAME.**




**7 PLUG IN THE TRY ME BUTTON AND ADAPTER INTO THE CONTROL BOX AS SHOWN BELOW:**




**AFTER PLUGGING IN THE TRY ME BUTTON, RUN IT THROUGH HIS LEFT SLEEVE SO IT HANGS FROM THE LEFT WRIST AREA, THEN RUN THE ADAPTER DOWN INSIDE HIS RIGHT PANTS LEG SO IT EXITS BEHIND HIS RIGHT SHOE**



**8 INFLATE THE RED BALLOON ATTACH IT TO THE HOLDER, THEN INSERT THE HOLDER INTO HIS RIGHT HAND.**



**9 PLUG IN THE ITEM, THEN GO TO THE CONTROL BOX TO CHOOSE ACTIVATION OPTIONS: "ON" TURN ON SENSOR FUNCTION "OFF" ACTIVATES THE TRY ME BUTTON FUNCTION.**



**Battery installation and replacement must be done by adult only.**

- Do NOT use rechargeable (nickel-cadmium) batteries
- Do NOT recharge NON-rechargeable batteries
- Do NOT mix old batteries with new or different types of batteries
- Do NOT mix alkaline standard (carbon-zinc) batteries or rechargeable (nickel-cadmium) batteries
- Do NOT place batteries near open flame or heat
- Remove batteries from product before storing for an extended period of time
- Only batteries of the same or equivalent type as recommended are to be used
  - Batteries are to be inserted with the correct polarity
  - Exhausted batteries are to be removed from the toy
  - The supply terminals are not to be short circuited
- **DISPOSAL** - This product contains batteries and electronics that may be harmful to the environment; they should not be discarded with normal household waste but taken to your local collection centre for recycling.
- Please retain this information for future reference.