



**MOTION
AND
SOUND
ACTIVATED!**

**¡MOVIMIENTO
Y SONIDO
ACTIVADOS!**

POSSESSED POLLY™

Rocking head!
Glowing eyes!
Scary sounds!

¡Cabeza bamboleante!
¡Ojos resplandecientes!
¡Sonidos espeluznantes!

3AA

Batteries Included
(for demo purposes only)

3 pilas "AA" incluidas
(solo con fines de demostración)

**Polly will possess YOU!
Mad rocking motion!
Evil glowing stare!
Crazy supernatural sounds!**

OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY
FROM CHILDREN

1. Carefully remove and discard the "Try Me" wire and packaging.
2. Insert 3 brand new "AA" alkaline batteries into the battery compartment located on the bottom of Doll's base.
3. Place switch on the module to the "ON" position.
4. Make a loud sound (clap) or wave hand in front of Possessed Polly™ to activate scary sequence!

NOTE: Keep the switch in the "OFF" position when not in use.

SURFACE WASHABLE ONLY.

All new materials:
polyester fibres, plastic, wire


Item #58628
POSSESSED POLLY™
is a trademark of Tekky.
Copyright © 2018 Tekky.
All Rights Reserved.
MADE IN CHINA

Manufactured for and
distributed by: Tekky,
Orland Park, IL 60467 USA

TekkyDesign.com

BATTERY INSTRUCTIONS AND CAUTIONS

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.



- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.



WARNING! CHOKING HAZARD—Small Parts.

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.

Not intended for use by children 14 years of age and younger.