



Evil glowing eyes & zombie cries!

¡Ojos malignos brillantes y gritos de zombi!

ZOMBIE DOLLS™ TAMMY TERROR™

3 LR44

3 LR44 button cell
batteries required
(included for
demo purposes only)

Se necesitan
3 pilas de botón LR44
(Incluidas solo para fines
de demostración)

She's the **TERROR** of the runway!
Evil glowing eyes and zombie cries!

OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS
AWAY FROM CHILDREN

1. Insert 3 brand new button cell LR44 batteries into the battery compartment located on back of your Zombie Doll™.
2. Press the button on Doll's chest to activate scary sequence!

SURFACE WASHABLE ONLY.

All new materials: polyester fibres, plastic, wire

Item #57501

ZOMBIE DOLL™ TAMMY TERROR™ is a trademark of Tekky.
Copyright © 2018 Tekky. All Rights Reserved.
MADE IN CHINA

Manufactured for and distributed by:
Tekky, Orland Park, IL 60467 USA

TekkyDesign.com

Also available!

BLOODY MARY™ (57502)

BRIDE™ (58637)



WARNING! CHOKING HAZARD—Small Parts.

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.

Not intended for use by children 14 years of age and younger.

BATTERY INSTRUCTIONS & CAUTIONS

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.

