



**MOTION  
AND  
SOUND  
ACTIVATED!**

**¡MOVIMIENTO  
Y SONIDO  
ACTIVADOS!**

# TERRIBLE TIM™

Evil glowing eyes!  
Scary sounds  
& movement!

¡Ojos malignos brillantes!  
¡Sonidos y movimientos  
espeluznantes!

**3AA**

Batteries Included  
(for demo purposes only)  
3 pilas "AA" incluidas  
(solo con fines de demostración)

Better run and hide...  
Terrible Tim™ is up to bat!  
Evil glowing eyes!  
Scary sounds and movement!  
Motion and sound activated

## OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE  
PARTS AWAY FROM CHILDREN

1. Carefully remove and discard the "Try Me" wire and packaging.
2. Insert 3 brand new "AA" alkaline batteries into the battery compartment located on bottom of module.
3. Place switch on the module to the "ON" position.
4. Make a loud sound (clap) or wave hand in front of Terrible Tim™ to activate scary sequences!

**NOTE:** Keep the switch in the "OFF" position when not in use.

**SURFACE WASHABLE ONLY.**

All new materials:  
polyester fibres, plastic, wire

Item #58634  
TERRIBLE TIM™  
is a trademark of Tekky.  
Copyright © 2018 Tekky.


All Rights Reserved.  
MADE IN CHINA

Manufactured for  
and distributed by:  
Tekky, Orland Park, IL 60467 USA

**TekkyDesign.com**

## BATTERY INSTRUCTIONS AND CAUTIONS

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.



**WARNING! CHOKING HAZARD—Small Parts.**

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.

Not intended for use by children 14 years of age and younger.