






HANGING SCARECROW

INSTALLATION AND OPERATING INSTRUCTIONS

PARTS:

1. FIGURE
(HEAD & BODY)
2. MODULE



1. Snap lock MODULE pole into the base located inside figure. (Match A to A)
2. Connect the wire running from MODULE to the wire located inside the figure. (Match B to B) (Match C to C).
3. Locate the metal loop on the back of the Hanging Scarecrow and mount the item to a wall, front door, or in any desired location. Bend the arms and hat

Reach inside the fabric on the figure. Insert (4) AA Alkaline batteries into the battery compartment located on the MODULE. Turn the switch to the ON position to activate the item. Move in front of the item to activate. Turn item OFF when not in use.

4. **NOTE:** A PIR sensor detects the human infrared signature and must be uncovered and facing forward to trigger this item. In order for the Hanging Scarecrow to function optimally, make sure the PIR sensor located on the front of the item is facing forward, and not blocked by any fabric.


WARNING
DO NOT TURN ITEM ON UNTIL YOU HAVE COMPLETELY FINISHED ASSEMBLY.
STAY CLEAR OF ITEM WHILE OPERATING.
DO NOT PLACE WEIGHT ON ITEM WHILE IN OPERATION.
**** FOR INDOOR USE ONLY ****

Battery Replacement should be performed by ADULTS ONLY
Installation:

1. Turn on/off switch to the off position and remove Phillips Head Screw from battery compartment lid located on the module..
2. Remove battery compartment lid.
3. Insert (4) AA batteries into battery compartment.

BATTERY CAUTION:

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
3. Do not put batteries in backwards. Positive (+) and negative (-) ends must face proper direction.
4. Do not leave batteries in product for long periods of non-use.
5. Do not dispose of batteries in fire.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help. This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, (2) this device must accept any interference that may cause undesired operation.



ALL NEW MATERIALS: METAL, FOAM, PLASTIC, POLYESTER. SURFACE WASHABLE ONLY

This is a Decoration - Not a Toy. Recommended for Ages 15 and Up. Visit us at: www.fun-world.net. Retain this package for future reference. Item #91849
©Fun World Div., Easter Unlimited, Inc., Carle Place, NY 11514. Fun World is a registered trademark of Easter Unlimited, Inc. All rights reserved. Made in China

