- This method requires a 12vDC linear actuator that does not draw more than 5amps.
- To program press REC on the PicoBoo. Press output button 1 to make the actuator go one direction and button 2 to make it go the other direction. Pressing both buttons will do nothing. Press REC when done recording.
- Wires shown in various colors only for clarity. Any color may be used.
- This data applies to all of our controllers that contain relays.



