



Trigger PicoVolt from a 1 relay wireless trigger



Activate two PicoVolts from A PicoBoo Plus with 2 relay wireless trigger



The PicoBoo Plus requires at least a 12V 1Amp power supply and each of the PicoVolts also require a 12V power supply with enough current for the devices you will control with them.