Directly Activating a 12vDC Solenoid with a Motion Sensor



- *Solenoid will activate when motion is detected. When motion is no longer detected solenoid will remain on from 2 to 30 seconds depending on motion sensor.*
- *When first powered-up the solenoid may fire on/off as the motion sensor warms up (about 30 seconds).*
- *The motion sensor must be of "normally open" type (FrightProps motion sensor are all "normally open", other's may not be)*